


3/4" Standard Steamhead



Installation Manual

For Tutorials and Troubleshooting visit www.thermasol.com/solutions

TSS-XXX

THERMASOL[®]

OVER 60 YEARS OF STEAM SHOWER INNOVATION

1 Important Information before You Install

PLEASE REVIEW WARNINGS BELOW AND LEAVE THIS MANUAL WITH HOMEOWNER

DO NOT USE THIS PRODUCT UNLESS YOU HAVE CONSULTED WITH YOUR DOCTOR AND RECEIVED WRITTEN PERMISSION TO DO SO. USE OF THIS PRODUCT MAY BE HAZARDOUS TO YOUR HEALTH.

PLEASE CONSULT YOUR PHYSICIAN BEFORE USING. IF YOU ARE PREGNANT, ELDERLY, HAVE HIGH BLOOD PRESSURE, DIABETES, SUFFERING FROM HEART DISEASE, ARE INTOXICATED, OR NOT IN GOOD HEALTH, DO NOT USE THIS STEAM BATH.

STEAM IS HOT! DO NOT TOUCH OR GO NEAR THE STEAMHEAD FROM THE TIME THE UNIT IS "ON," UP TO ONE HOUR AFTER IT HAS SHUT OFF. SEVERE BURNS WILL OCCUR IF YOU COME IN CONTACT WITH THE STEAMHEAD OR STEAM EMITTING FROM THE STEAMHEAD.

NEVER ATTEMPT TO FILL AROMA RESERVOIR ON THE STEAMHEAD WHEN UNIT IS IN THE "ON" POSITION. SEVERE BURNS WILL OCCUR.

DO NOT USE THERMASOL AROMATHERAPY OILS, SKIN CARE PRODUCTS OR ANY PRODUCT ASSOCIATED WITH YOUR THERMASOL UNIT WITHOUT CONSULTING WITH YOUR ALLERGIST OR DOCTOR BEFORE USE. THESE PRODUCTS MAY BE HAZARDOUS TO YOUR HEALTH.

DO NOT USE STEAM ROOM WHILE UNDER THE INFLUENCE OF ALCOHOL OR DRUGS, AS THIS CAN BE HAZARDOUS TO YOUR HEALTH.

YOUR SHOWER MAY BE A SLIP-AND-FALL HAZARD. CHECK WITH YOUR CONTRACTOR OR FLOORING MANUFACTURER REGARDING THE SAFE USE OF YOUR FLOORING IN A STEAM APPLICATION. SLIPPING AND FALLING INTO THE STEAMHEAD ITSELF OR INTO THE STREAM OF STEAM EMITTING FROM THE STEAMHEAD WILL CAUSE SERIOUS BURNS OR PHYSICAL INJURY.

IF YOU ARE FEELING UNCOMFORTABLE, DIZZY, FAINT, OR STARTING TO FALL ASLEEP, IMMEDIATELY EXIT THE STEAM ROOM.


DO NOT USE STEAM ROOM IF YOU ARE UNDER THE AGE OF 16 UNLESS SUPERVISED BY AN ADULT.

THERMASOL STEAM BATH GENERATORS ARE NOT DESIGNED TO BE USED FOR SPACE HEATING PURPOSES.

THERMASOL STEAM BATH GENERATORS ARE FOR INDOOR USE ONLY. THEY SHOULD NEVER BE LOCATED OUTSIDE THE HOME.

All products must be installed in accordance with installation instructions provided. Failure to do so may invalidate warranty at manufacturer's discretion. ©2021 ThermaSol.


2 Tools and Materials



TSS-XXX
Steamhead & Escutcheon



Silicone




Installation instructions

Materials/Tools needed:

- TSS-XXX Steamhead & Escutcheon
- Pipe Wrench
- Silicone
- 1-1/4" Masonry Drill Bit
- Other materials as required

3 Installation



*Prior to any work being done, turn the power and water off to the product and read these instructions in their entirety. Insure plumbing is cool enough to work on.

1. Drill a 1-1/4" diameter hole in the shower wall. Locate 12"-16" from steam room floor, keep away 6" from steam room corner, and as far away from the user as possible.
 - CAUTION: The steam head is hot! And should not be located near a seat or bench! Locate at the maximum distance from user(s) as possible.
2. Connect 3/4" F.I.P. copper pipe or copper tubing and 3/4" brass union onto the steam outlet. Run a 3/4" copper pipe from the union to the 1-1/4" hole in wall. Do not use galvanized pipe.
3. Attach the steam head and escutcheon to the copper pipe. CAUTION: Do not obstruct the steam line with any shut-off valves, plugs or caps. ALL steam generators are designed to build NO PRESSURE.
 - The steam line can run up, down, or horizontal; but cannot run down and then up. If it does, a steam trap will be produced at the low point blocking the flow of steam. Insulate the steam outlet piping if the piping run exceeds 10 feet or is exposed to cold areas. NOTE: Use steam rated insulation (225°F Min.).
4. You may turn power back on.

****Avoid contact with steam head! It will burn you. Avoid direct contact with the steam coming out of the steamhead! It is extremely hot! It will burn you!**



1958 STEAM WAY ROUND ROCK, TX 78665
PHONE: 800.776.0711 | FAX: 800.556.5257 | WWW.THERMASOL.COM

81258_NC